

Group 2 Assignment: Disk Imaging and file recovery.

This assignment was completed by 3 participants namely:

- 1. Fumnanya Divine Chukwuma**
- 2. Apena Dare David**
- 3. Maxwell Malon**

For this assignment, we were tasked to learn hands-on digital evidence collection techniques and to be able to accomplish that we utilized an FTK Imager tool and an Autopsy tool.

FTK Imager:

This is a forensic imaging tool made by AccessData. It creates forensic images and it is used to capture either a bit-for bit copy of a disk or even just a partition for analysis. It's a proper way for analysis to avoid analysing a live disk.


Autopsy:

This is an open-source digital forensics platform and it is used for analysis and recovery.


For FTK Imager:



Creating a forensic image:


A live logical image was done and no write-blocker was available.



We will be using the Physical drive source evidence type because it would image the contents of the physical drive that has been attached to this forensic workspace (this device). Other source evidence types are available for use and differ in speed as regards to the imaging process.








Common choices of image types are:


- Raw (dd): This is raw bit-for-bit. It is a very simple image type and it is widely compatible.
- E01 (Expert witness): This supports compression and metadata, it is often used in forensics.

We will utilize “Raw.dd” for this assignment.


This is where we name our evidence item for easy identification.



And this is where we choose destination folder and set the image filename (also important for easy identification).



After setting all these permissions and parameters, we can now start the FTK image creation.




Creating Image... — □ ×

Image Source:

Destination:

Status:

Progress



Elapsed time:

Estimated time left:


Creating Image... — □ ×

Image Source:

Destination:

Status:

Progress



Elapsed time:

Estimated time left:


Creating Image... — □ ×

Image Source:

Destination:

Status:

Progress




Elapsed time:


Estimated time left:

Elapsed time of image creation is estimated at 20 mins and 5 Seconds.

This process is the verification process of the image created so as to generate the hashes used.



As we can see, the computed hashes have been generated successfully and we can see that they are no errors or bad blocks found in the image.



This is the text document also generated after the FTK image creation was complete. This text document entails all information as regards the image creation like the type of device imaged (In this case a USB drive), date and time of creation down to the entire time the FTK imager used to create the image and many more.

Creation Report:

Created By Exterro® FTK® Imager 4.7.3.81

Case Information:

Acquired using: ADI4.7.3.81

Case Number: Case 0

Evidence Number: EV 0-09-2025

Unique description: Imaging of Case 0 For Group 2

Examiner: James Fumnanya

Notes: For Cyber Security assignment completion Purposes.

Information for C:\Users\Chukwuma Fumnanya D\Downloads\FTK Imaging results\Cyber Security Assignment 7 FTK Image 0-09-2025:

Physical Evidentiary Item (Source) Information:

[Device Info]

Source Type: Physical

[Drive Geometry]

Cylinders: 1,937

Tracks per Cylinder: 255

Sectors per Track: 63

Bytes per Sector: 512

Sector Count: 31,129,600

[Physical Drive Information]

Drive Model: Generic Flash Disk USB Device

Drive Serial Number: _____C

Drive Interface Type: USB

Removable drive: True

Source data size: 15200 MB

Sector count: 31129600

[Computed Hashes]

MD5 checksum: e521b2d22247e5a0581b043421debff5

SHA1 checksum: dd7ce0ef1ef8ab2eda2ec127af65caf002c2c472

Image Information:

Acquisition started: Wed Sep 17 01:17:15 2025

Acquisition finished: Wed Sep 17 01:37:20 2025

Segment list:

C:\Users\Chukwuma Fumnanya D\Downloads\FTK Imaging results\Cyber Security Assignment 7 FTK Image 0-09-2025.001

C:\Users\Chukwuma Fumnanya D\Downloads\FTK Imaging results\Cyber Security Assignment 7 FTK Image 0-09-2025.002

C:\Users\Chukwuma Fumnanya D\Downloads\FTK Imaging results\Cyber Security Assignment 7 FTK Image 0-09-2025.003

C:\Users\Chukwuma Fumnanya D\Downloads\FTK Imaging results\Cyber Security Assignment 7 FTK Image 0-09-2025.004

C:\Users\Chukwuma Fumnanya D\Downloads\FTK Imaging results\Cyber Security Assignment 7 FTK Image 0-09-2025.005

C:\Users\Chukwuma Fumnanya D\Downloads\FTK Imaging results\Cyber Security Assignment 7 FTK Image 0-09-2025.006

C:\Users\Chukwuma Fumnanya D\Downloads\FTK Imaging results\Cyber Security Assignment 7 FTK Image 0-09-2025.007

C:\Users\Chukwuma Fumnanya D\Downloads\FTK Imaging results\Cyber Security Assignment 7 FTK Image 0-09-2025.008

C:\Users\Chukwuma Fumnanya D\Downloads\FTK Imaging results\Cyber Security Assignment 7 FTK Image 0-09-2025.009

C:\Users\Chukwuma Fumnanya D\Downloads\FTK Imaging results\Cyber Security Assignment 7 FTK Image 0-09-2025.010

C:\Users\Chukwuma Fumnanya D\Downloads\FTK Imaging results\Cyber Security Assignment 7 FTK Image 0-09-2025.011

COMPUTED HASH : e521b2d22247e5a0581b043421debff5

COMPUTED HASH : dd7ce0ef1ef8ab2eda2ec127af65caf002c2c472

Image Verification Results:


Verification started: Wed Sep 17 01:37:32 2025

Verification finished: Wed Sep 17 01:46:32 2025

MD5 checksum: e521b2d22247e5a0581b043421debff5 : verified

SHA1 checksum: dd7ce0ef1ef8ab2eda2ec127af65caf002c2c472 : verified

For Autopsy:



This is the UI of the open source Autopsy software.

To begin the process of investigation we have to create a “New case” and as usual set the case name and the base directory. Please note that we created a disk image of the external drive into our forensic environment/device so therefore to avoid complications of the process during our investigation/autopsy we will need to move the results of this investigation outside this forensic environment (moving it out of the same drive where investigation is being conducted).

Steps

1. Case Information
2. Optional Information

Case Information

Case Name:

Base Directory:

Case Type: ☒ Single-User ☐ Multi-User

Case data will be stored in the following directory:

< Back

Next >

Finish

Cancel

Help

Organizations are used to provide additional contact information for the content they manage.

Organization Details

Organization Name:

Organizations

Not Specified

Add New Organization

×

Organization Name:

Point of Contact:

Name:

Email:

Phone:

OK


Cancel

New


Edit

Delete


Close



We could also fill the forms provided for identification purposes and accountability.





Now we create a “new host” and hostname because we are first time users of the software.




Thereafter, we look for our FTK image file where we have our image that requires investigation. We do that by clicking on “Disk image or VM file” and click “Next” which would take us to the next page.

This is the next page and we have to select the file path using the “Browse” option and select the FTK image file. Thereafter, it would select the sector size and will give us the hash information (for accountability).






This is the stage of “Ingest” where autopsy uses investigation filters to generate results concerning a particular image that is being investigated. Marking more filters means more time and items for autopsy to generate results but for this assignment, we will only use the File type identification, PhotoRec Carver, EXI, Hash lookup, Picture Analyzer, Keyword search, Recent Activity and others as marked in the screenshot and then click “Next”.



The process will take a lot of time and we need to leave it for a while so as to enable it generate all the information needed to perform the investigation.




This page is displayed once Autopsy is done generating all the items for investigation. Now you can click them one by one to commence your investigation.

If we decide to check the files that have been deleted previously from the device being investigated, we can see the files listed with the timestamp of their deletion, creation and modification and there is also option to recover the deleted file discovered.

The screenshot shows the Autopsy 4.22.1 interface. The left sidebar displays a tree view of data sources, including 'Deleted Files' (1715) and 'File System' (1715). The main window is titled 'Listing' and shows a table of deleted files. The table has columns for Name, S, C, O, Modified Time, Change Time, Access Time, and Created Time. The files listed include scan.pdf, scan0001.pdf, moffice_wr_ch, Invoice For Mrs Juliet (1) - Copy.xlsx, _WRD0000.tmp, _WRL0001.tmp, Juliet Appt Letter 1 - Copy.docx, _WRD0002.tmp, _WRL0003.tmp, Lagoon collins Quotation 6.70pdf.xlsx, ~\$Lagoon collins Quotation 6.70pdf.xlsx, _A9E0F10, and AC487B3.tmp. The 'Created Time' column shows various timestamps, including 1980-01-01 00:00:00 TRT and 2018-08-16 21:31:44 T. A 'Save Table as CSV' button is visible in the top right corner of the table area.

Name	S	C	O	Modified Time	Change Time	Access Time	Created Time
scan.pdf				1980-01-01 00:00:00 TRT	0000-00-00 00:00:00	1980-01-01 00:00:00 TRT	1980-01-01 00:00:00 T
scan0001.pdf				1980-01-01 00:00:00 TRT	0000-00-00 00:00:00	2018-12-10 00:00:00 TRT	1980-01-01 00:00:00 T
moffice_wr_ch				2018-08-31 09:06:52 TRT	0000-00-00 00:00:00	2018-08-31 09:06:52 T	2018-08-31 09:06:52 T
Invoice For Mrs Juliet (1) - Copy.xlsx				2018-08-16 21:07:02 TRT	0000-00-00 00:00:00	2018-08-17 00:00:00 TRT	2018-08-17 11:21:43 T
_WRD0000.tmp				2018-08-17 11:36:06 TRT	0000-00-00 00:00:00	2018-08-17 00:00:00 TRT	2018-08-16 21:31:44 T
_WRL0001.tmp				2018-08-16 21:31:20 TRT	0000-00-00 00:00:00	2018-08-17 00:00:00 TRT	2018-08-16 21:31:44 T
Juliet Appt Letter 1 - Copy.docx				2018-08-17 11:36:06 TRT	0000-00-00 00:00:00	2018-08-17 00:00:00 TRT	2018-08-16 21:31:44 T
_WRD0002.tmp				2018-08-17 11:37:40 TRT	0000-00-00 00:00:00	2018-08-17 00:00:00 TRT	2018-08-16 21:31:44 T
_WRL0003.tmp				2018-08-17 11:36:06 TRT	0000-00-00 00:00:00	2018-08-17 00:00:00 TRT	2018-08-16 21:31:44 T
Lagoon collins Quotation 6.70pdf.xlsx				2018-03-09 06:52:08 TRT	0000-00-00 00:00:00	2018-08-23 00:00:00 TRT	2018-08-18 18:37:20 T
~\$Lagoon collins Quotation 6.70pdf.xlsx				2018-08-23 08:49:24 TRT	0000-00-00 00:00:00	2018-08-23 00:00:00 TRT	2018-08-23 08:49:04 T
_A9E0F10				2018-08-23 08:49:24 TRT	0000-00-00 00:00:00	2018-08-23 00:00:00 TRT	2018-08-18 18:37:20 T
AC487B3.tmp				2018-03-09 06:52:08 TRT	0000-00-00 00:00:00	2018-08-23 00:00:00 TRT	2018-08-18 18:37:20 T

We can also decide to check the metadata generated for each file on the device undergoing forensic analysis and the metadata is very important because it shows whatever has been done to that device or with that file. And also, an investigator could also download whatever information discovered during investigation by saving it as a CSV file and can use that to create whatever investigative report he or she wanted to create.



So all this and many more can be done on any device subject to investigation. All you need are these important tools.

The FTK imager for creating the image of the device in question and then Autopsy for investigative analysis.